

# Parts list

- 01 Air cap ring
- 02 Air cap gasket
- 03 Air cap
- 04 Air cap retaining clip
- 05 Air cap ring seal
- 06 Nozzle
- 07 Nozzle gasket
- 08 Atmolysis ring
- 09 Atmolysis ring gasket
- 10 Fluid joint pad
- 11 Fluid joint
- 12 Fluid joint plastic
- 13 Plastic filter
- 14 Cup
- 15 Pattern split washer
- 16 Pattern seal gasket
- 17 Pattern seat
- 18 Pattern needle

- 19 Pattern adj. knob
- 20 Needle plastic
- 21 Needle spring
- 22 Needle screw
- 23 Split washer
- 24 O ring
- 25 O ring
- 26 Valve seat
- 27 Valve seal gasket
- 28 Valve spindle
- 29 Valve spring
- 30 Seal ring
- 31 Fluid needle seat
- 32 Fluid needle
- 33 Fluid needle adj. seat
- 34 Needle spring
- 35 Needle spring gasket
- 36 Needle adj. knob

- 37 Air inlet connctor
- 38 Gun body
- 39 Air needle
- 40 Air adj. seat
- 41 Air adj. stem
- 42 Master airflow bush
- 43 Split washer
- 44 Trigger
- 45 Trigger pin screw
- 46 Trigger pin
- 47 Hexagon wrench
- 48 Steel brush
- 49 Wrench
- 50 Fine needle
- 51 Nylon brush
- 52 Cap of cup thread

